

**VIVE**  
COMFORT  
Operation Manual

**VIVE**  
COMFORT  
Operation Manual



# TP-P-705

## Vive Comfort

PO Box 3377

Springfield, MO 65804

Toll Free: 888-776-1427

Web: [www.vivecomfort.com](http://www.vivecomfort.com)

Hours of Operation: M-F 9AM - 6PM Eastern

### Table of Contents


	Page
Table of Contents	1
Thermostat Quick Reference	2-4
Thermostat Operation	5-6
Warranty Information	7



### Caution:

Equipment damage hazard. Do not operate the cooling system if the outdoor temperature is below 50 °F (10 °C) to prevent possible compressor damage.

Una version en español de este manual se puede descargar en la pagina web de la compania.



① LCD Display

② Glow in the dark light button

③ Fan Switch

④ System Switch

⑤ Temperature Setpoint Buttons

⑥ User Buttons

① **LCD Display**  
See page 4 for details about this display read out.

② **Glow in the dark light button**  
The glow in the dark light button will self illuminate for several hours after exposure to ambient light. This button turns on the display light when pressed.

③ **Fan Switch**  
Select **ON** or **AUTO**. **ON** will run the fan continuously. **AUTO** will cycle the fan on only when the heating or cooling system is on.

④ **System Switch**  
Selects the operation mode on your HVAC system. Selecting **HEAT** turns on the heat mode. Selecting **COOL** turns on the air conditioning mode. Selecting **OFF** turns both heating and cooling off.


⑤ **Temperature Setpoint Buttons**  
Press the ▲ or ▼ buttons to select the desired room temperature.

⑥ **User Buttons**  
Use these buttons to set up your programming options. Refer to the next page for detail.



### Caution:

When the battery icon  appears replace your AA batteries immediately. Failure to do so may result in your heating & cooling system becoming inoperable. Freezing or over heating can occur.




- ① **Indicates the current room temperature**
- ② **Time and day of the week**
- ③ **Low Battery Indicator:** Replace batteries when this indicator is shown.
- ④ **Button Options**
- ⑤ **Program Time Periods:** This thermostat has 4 programmable time periods per day.
- ⑥ **System Operation Indicators:**  
The **COOL ON \***, **HEAT ON** or **FAN** icon will display when the **COOL, HEAT,** or **FAN** is on. **Note:** The compressor delay feature is active if these icons are flashing. The compressor will not turn on until the 5 minute delay has elapsed.
- ⑦ **Hold** is displayed when the thermostat program is permanently overridden.
- ⑧ **Setpoint:** Displays the user selectable setpoint temperature.




**Important:**  
The low battery indicator is displayed when the AA battery power is low. If the user fails to replace the battery within 21 days, the screen will only show the low battery indicator but maintain all functionality. If the user fails to replace the batteries after an additional 21 days (days 22-42 since first "low battery" display) the set points will change to 55°F (Heating) and 85°F (Cooling). If the user adjusts these setpoints away from these it will hold for 4 hours then return to either 55°F or 85°F. After day 63 the batteries must be replaced immediately to avoid freezing or overheating because the thermostat will shut the unit off until the battery is changed.

## Battery Door Information



Replace with 2 AA Alkaline Batteries. High quality Alkaline batteries are recommended.



Use the finger bevel on the lower portion of the thermostat to open the easy access battery door.

Simple operating instructions are found on the back of the battery door.

## Temporary and Permanent Hold Feature

**Temporary Hold:** The thermostat will display **HOLD** and **RUN SCHED** on the left of your screen when you press the ▲ or ▼ key. If you do nothing, the temperature will remain at this setpoint temporarily until next time period. Your program setpoint will then replace your temporary setpoint.

**Permanent Hold:** If you press the **HOLD** key at the left of your screen, you will see **HOLD** appear below the setpoint temperature in the display. The thermostat will now permanently stay at this setpoint and can be adjusted using the ▲ or ▼ keys.


**To return to program:** Press the **RUN SCHED** key at the left of your screen to exit either temporary or permanent hold.

## Filter Change Reminder







If your HVAC contractor has configured the thermostat to remind you when the air filter needs to be changed, you will see **FILT** in the display when your air filter needs to be changed.

**Resetting the filter change reminder:** When **FILT** reminder is displayed, you should change your air filter and reset the reminder by holding down the second button from the top left side of the thermostat for 3 seconds.

Hold down 3 seconds,  
to reset filter reminder.







## Set Time

1. With system switch set to OFF, press the **MENU** button
2. Press **SET TIME**
3. Day of the week will be flashing. Use the  or  key to select the current day of the week.
4. Press **NEXT STEP**
5. The current hour is flashing. Use the  or  key to select the current hour. When using 12-hour time, make sure the correct a.m. or p.m. choice is selected.
6. Press **NEXT STEP**
7. Minutes are now flashing. Use the  or  key to select current minutes.
8. Press **DONE** when completed.

## Set Program Schedule

To customize your program schedule, follow these steps

**Weekday:**

1. Select **HEAT** or **COOL** with the system switch. **Note:** You have to program heat and cool each separately.
2. Press the **MENU** button
3. Press SET SCHED. Note: Monday-Friday is displayed and the WAKE icon is shown. You are now programming the wake time period for the weekday setting.
4. Time is flashing. Use the  or  key to make your time selection for the weekday WAKE time period.
5. Press **NEXT STEP**
6. The setpoint temperature is flashing. Use the  or  key to make your setpoint selection for the weekday wake period.
7. Press **NEXT STEP**
8. Repeat steps 4 thru 7 for weekday **LEAVE** time period, for weekday **RETURN** time period, and for weekday **SLEEP** time period.

Continued on next page...

## Set Program Schedule

To customize your program schedule, follow these steps

### Saturday:

Repeat steps 4 thru 7 for Saturday **WAKE** time period, for Saturday **LEAVE** time period, for Saturday **RETURN** time period, and for Saturday **SLEEP** time period.

### Sunday:

Repeat steps 4 thru 7 for Sunday **WAKE** time period, for Sunday **LEAVE** time period, for Sunday **RETURN** time period, and for Sunday **SLEEP** time period.



### Important:

You will see a **TECH SET** option after the **MENU** key is pressed.

This **TECH SET** key is for installer configuration and should **NOT** be changed unless you consult your professional heating and air conditioning technician.

## Warranty Registration

Your new thermostat has a 5 year limited warranty. You must register your thermostat within 60 days of installation. Without this registration the warranty period will begin on date of manufacture. For warranty issues please contact the HVAC professional that installed this product. You can register your new thermostat in 2 ways:

### Online

Go to the company website, select warranty registration and fill out a short registration form.

### Mail

Complete the form below and mail it to the address shown.

## Warranty Registration

Name: \_\_\_\_\_ Thermostat Model: \_\_\_\_\_

Address: \_\_\_\_\_ Date Installed: \_\_\_\_\_

==

City: \_\_\_\_\_ Complete form and mail to:

State: \_\_\_\_\_ **Thermostat Warranty Registration**

Zip: \_\_\_\_\_ Vive Comfort

PO Box 3377

Springfield, MO 65804

**Cut Out For  
Warranty Registration**



**VIVE**  
COMFORT  
[www.vivecomfort.com](http://www.vivecomfort.com)