





Page

Vive Comfort

P.O. Box 3377 Springfield, MO 65808-3377 Toll Free : 888-776-1427 Web: www.vivecomfort.com Hours of Operation: M-F 9AM - 6PM Eastern


Table of Contents

Table of Contents1Thermostat Operation2-3Thermostat Quick Reference4-6Thermostat Warranty Information7

Una version en español de este manual se puede descargar en la pagina web de la compañia.



Equipment damage hazard. Do not operate the cooling system if the outdoor temperature is below 50 °F (10 °C) to prevent possible compressor damage.



1 LCD 2 Fan Switch

System Switch



5 Easy change battery door

1 LCD Display

See page 6 for details about this display read out.

2 Fan Switch

Select ON or AUTO. ON will run the fan continuously. AUTO will cycle the fan on only when the heating or cooling system is on.

3 System Switch

Selects the operation mode on your HVAC system. Selecting HEAT turns on the heat mode. Selecting COOL turns on the cool mode. Selecting OFF turns both heating and cooling off.


4 Temperature Setpoint Buttons

Press the + or - buttons to select the desired room temperature.



Battery Door Information

2 AA Alkaline Batteries, High quality Alkaline batteries are recommended.



Simple operating instructions are found on the back of the battery door.

Use the finger bevel on the lower portion of the thermostat to open the easy access battery door.



When the battery icon appears replace your AA batteries immediately. Failure to do so may result in your heating & cooling system becoming inopérable. Freezing or overheating can occur.



The low battery icon is displayed when the AA battery power is low. Whenever the thermostat detects low battery voltage from the AA batteries, the low battery icon will begin flashing on the screen for 21 days (if the batteries are not changed). If the batteries are not changed 22 days after the thermostat detects low battery voltage, the thermostat screen will only show the flashing battery icon until buttons are pressed. If the batteries are not changed 43 days after the thermostat detects low battery voltage, the thermostat screen will only show the flashing battery icon until buttons are pressed and the set points will offset to 85°F/29°C in cooling and 55°F/13°C in heating. At this stage, set point changes can be made temporarily but, the set points will change back to defaulted values after a 4-hour period. The thermostat will continue to perform this low battery flashing, temperature offset condition until the internal voltage threshold is reached. When the thermostat internal voltage threshold is reached, all relays will be opened and the thermostat will become inoperable until new batteries are installed.

Thermostat Quick Reference

System Operation Displays the Indicators: selected setpoint ON will display when temperature. the COOL or HEAT is on. COOL Set'At **HEAT** ON STAGE LOW

Indicates the current room temperature.

Low Battery Indicator:

Replace batteries when indicator is shown.

Warranty Registration

Your new thermostat has a 2 year limited warranty. You must register your thermostat within 60 days of installation. Without this registration the warranty period will begin on date of manufacture. For warranty issues please contact the HVAC professional that installed this product. You can register your new thermostat in 2 ways:

Online

Go to the company website, select warranty registration and fill out a short registration form.

Mail

Complete the form below and mail it to the address shown.

Warranty Registration

Name: Address:	
City: State: Zip:	Complete form and mail to: Thermostat Warranty Registration Vive Comfort P.O. Box 3377 Springfield, MO 65808-3377

Cut Out For Warranty Registration

