

Vive Comfort

P.O. Box 3377
Springfield, MO 65804
Toll Free : 888-776-1427
Web: www.vivecomfort.com
Hours of Operation: M-F 9AM - 6PM Eastern

Thermostat Application Guide

| Description | |
|---|-----|
| Gas or Oil Heat | Yes |
| Electric Furnace | Yes |
| Heat Pump (No Aux. or Emergency Heat) | Yes |
| Heat Pump (With Aux. or Emergency Heat) | No |
| Multi-Stage Systems | No |
| Heat Only Systems | Yes |
| Heat Only Systems - Floor or Wall Furnace | Yes |
| Cool Only Systems | Yes |
| Millivolt | Yes |

Power Type

Battery Power
Hardwire (Common Wire)
Hardwire (Common Wire) with Battery Backup

A trained, experienced technician must install this product.

Carefully read these instructions. You could damage this product or cause a hazardous condition if you fail to follow these instructions.

Una version en espanol de este manual se puede descargar en la pagina web de la compania.

Table of Contents

Page

| | |
|----------------------------|-------|
| Installation Tips | 2-3 |
| Thermostat Quick Reference | 4-5 |
| Wiring | 6 |
| Wiring Diagrams | 7-8 |
| Features | 9 |
| Technician Setup | 10-13 |
| Programming Thermostat | 13-16 |

Specifications


The display range of temperature ... 41°F to 95°F (5°C to 35°C)
The control range of temperature.... 44°F to 90°F (7°C to 32°C)
Swing (cycle rate or differential) Heating is adjustable from 0.2° to 2.0°
Cooling is adjustable from 0.2° to 2.0°
Power source 18 to 30 VAC, NEC Class II, 50/60 Hz for hardwire
Battery power from 2 AA Alkaline batteries
Operating ambient 32°F to +105°F (0°C to +41°C)
Operating humidity 90% non-condensing maximum
Dimensions of thermostat 4.7"W x 4.4"H x 1.1"D

1 © U.S. Registered Trademark. Patents pending
Copyright © 2018 All Rights Reserved.

Rev. 1821

Wall Locations

The thermostat should be installed approximately 4 to 5 feet above the floor. Select an area with average temperature and good air circulation.



Installation Tip


Pick an installation location that is easy for the user to access. The temperature of the location should be representative of the building.

Do not install thermostat in locations:

- Close to hot or cold air ducts
- That are in direct sunlight
- With an outside wall behind the thermostat
- In areas that do not require conditioning
- Where there are dead spots or drafts (in corners or behind doors)
- Where there might be concealed chimneys or pipes

Subbase Installation

- 1 Horizontal Mount
- 2 Vertical Mount



For vertical mount put one screw on the top and one screw on the bottom.
For horizontal mount put one screw on the left and one screw on the right.

Installation Tip: Electrical Hazard

Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.


Mercury Notice

All of our products are mercury free. However, if the product you are replacing contains mercury, dispose of it properly. Your local waste management authority can give you instructions on recycling and proper disposal.

Installation Tips


Mount Thermostat

Align the 4 tabs on the subbase with corresponding slots on the back of the thermostat, then push gently until the thermostat snaps in place.



Battery Installation


Battery installation is recommended even if thermostat is hardwired (C terminal connected). When thermostat is hardwired and batteries are installed, the thermostat will activate a compressor delay of 5 minutes when the thermostat detects a power outage from the hardwired power supply.



Important:

High quality alkaline batteries are recommended. Rechargeable batteries or low quality batteries do not guarantee a 1-year life span.

Insert 2 AA Alkaline batteries (included). High quality alkaline batteries are recommended.




Simple operating instructions are found on the back of the battery door.

About The Badge


All of our thermostats use the same universal magnetic badge. Visit the company website to learn more about our free private label program.

Gently slide a screwdriver into the bottom edge of the badge. Gently turn the screwdriver counter clockwise. The badge is held on by a magnet in the well of the battery door. The badge should pry off easily. **DO NOT USE FORCE.**




Thermostat Quick Reference

Getting to know your thermostat



- 1 LCD Display
- 2 Fan Switch
- 3 System Switch
- 4 Easy change battery door
- 5 Temperature Setpoint Buttons
- 6 User Buttons

Getting to know your thermostat



- ① Indicates the current room temperature
- ② Time and day of the week
- ③ **Low Battery Indicator:** Replace batteries when this indicator is shown.
- ④ **Program Time Periods:** This thermostat has 4 programmable time periods per day.
- ⑤ **System Operation Indicators:** ON will display when the COOL or HEAT is on. Compressor delay feature is active if flashing.
- ⑥ **Hold** is displayed when the thermostat program is permanently overridden.
- ⑦ **Setpoint:** Displays the user selectable setpoint temperature.

Important

The low battery indicator is displayed when the AA battery power is low. If the user fails to replace the battery within 21 days, the screen will only show the low battery indicator but maintain all functionality. If the user fails to replace the batteries after an additional 21 days (days 22-42 since first "low battery" display) the setpoints will change to 55°F (Heating) and 85°F (Cooling). If the user adjusts the setpoint away from either of these, it will hold for 4 hours then return to either 55°F or 85°F. After day 63 the batteries must be replaced immediately to avoid freezing or overheating because the thermostat will shut the unit off until the batteries are changed.

Wiring

1. If you are replacing a thermostat, make note of the terminal connections on the thermostat that is being replaced. In some cases the wiring connections will not be color coded. For example, the green wire may not be connected to the **G** terminal.
2. Loosen the terminal block screws. Insert wires then retighten terminal block screws.
3. Place nonflammable insulation into wall opening to prevent drafts.



Caution: Electrical Hazard

Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.



Warning:

All components of the control system and the thermostat installation must conform to Class II circuits per the NEC Code.

Terminal Designations

- | | |
|--|---|
| C Common wire from system transformer | RH Transformer power for heating |
| O Heat pump changeover valve energized in cooling | RC Transformer power for cooling |
| B Heat pump changeover valve energized in heating | G Fan relay |
| W Heat relay | Y Compressor relay |

Wiring Tips

RH & RC Terminals

For single transformer systems, leave the jumper wire in place between RH and RC. Remove jumper wire for two transformer systems.

C Terminal

The C (common wire) terminal does not have to be connected when the thermostat is powered by batteries.

Heat Pump Systems (With NO AUX or Emergency Heat)

If wiring to a heat pump, use a small piece of wire (not supplied) to connect terminals W and Y.

Wire Specifications

Use shielded or non-shielded 18-22 gauge thermostat wire.



Installation Tip: Do not overtighten terminal block screws, as this can damage the terminal block. A damaged terminal block can keep the thermostat from fitting on the subbase correctly or cause system operation issues. **Max Torque = 6in-lbs.**

Features

Temporary and Permanent Hold Feature


Note: This is a programmable thermostat, and will always be running a programmed schedule. However, it can be overridden with a Temporary or Permanent Hold.

Temporary Hold: With the system in Heat or Cool, anytime the set-at temperature is changed with the + or - buttons, the thermostat will enter a Temporary Hold. This will be indicated by "HOLD" flashing below the set-at temperature and will remain in this hold until the next programmed time period begins.

Permanent Hold: To enter a Permanent Hold, press the Hold/Run button while "HOLD" is flashing. The word "HOLD" will remain on continuously, indicating a Permanent Hold.

To Return to Running Schedule: To manually exit this hold and return to scheduled program, press Hold/Run button or cycle the System Switch.

Tech Settings



Gas or Electric Setup

Gas: For all systems that control the fan during a call for heat, put the fan operation jumper pin to the **GAS** position.

Electric: Select Electric to have the thermostat control the fan during a call for heat.

Fahrenheit/Celsius Display


Select **F** or **C** with the jumper pin on the back of the thermostat. **F** is for Fahrenheit and **C** is for Celsius.

12 or 24 Hour Time


12 or 24 hour (military time) can be selected with the jumper pin.

- 1 Power supply
- 2 Factory-installed jumper. Remove only when installing on 2-transformer systems
- 3 Use either O or B terminals for changeover valve
- 4 Use a small piece of wire (not supplied) to connect W and Y terminals
- 5 Set fan operation setting to Electric
- 6 Optional 24 VAC common connection when thermostat is used in battery power mode


Typical 1H/1C System: 1 Transformer




Typical 1H/1C System: 2 Transformer




Typical Heat-Only System




Typical Heat Only System With Fan



Typical Cool-Only System



5 Typical 1H/1C Heat Pump System



7

8

Tech Settings

Tech Settings

Technician Setup Menu

This thermostat has a technician setup menu for easy installer configuration. To setup the thermostat for your particular application:

Filter Change Reminder

- To enter Filter change reminder, press and hold the Time and Hold/Run buttons together for 3 seconds.
- Use **+** and **-** buttons to set.
- Press Hold/Run button to exit.

All other Steps

- To enter all other steps press and hold **+** and **-** buttons together for 3 seconds. This 3 second delay is designed so that homeowners do not accidentally access the installer settings.
- Use **+** and **-** buttons to set.
- Press Program button to advance to the next step.
- Press Hold/Run button to exit.

Swing Setting Tip

Temperature swing, sometimes called differential or cycle rate, can be customized for this individual application. For most applications choose a swing setting that is as long as possible without making the occupants uncomfortable.

| Tech Settings | LCD Will Show | Adjustment Options | Default |
|------------------------------|---------------|--|---------|
| Filter Change Reminder | OFF SE FI | You can adjust the filter change reminder from OFF to 2000 hours of runtime in 50 hour increments. Tap the second button from the top left side of the thermostat to display the current filter elapsed runtime. | OFF |
| Room Temperature Calibration | CAL 0 | You can adjust the room temperature display to read 4° above or below the factory calibrated reading. | 0 |
| Minimum Compressor On Time | OFF ON AN | You can select the minimum compressor run time from "off", "3", "4", or "5" minutes. If 3, 4, or 5 is selected, the compressor will run for at least the selected time before turning off. | OFF |
| Compressor Short Cycle Delay | ON OF 00 | Selecting "ON" will not allow the compressor to be turned on for 5 minutes after the last time the compressor was switched off. Select "OFF" to remove this delay. | ON |
| Cooling Swing | dFCO 05 | The cooling swing setting is adjustable from 0.2" to 2". For example: A swing setting of 0.5" will turn the cooling on at approximately 0.5" above the setpoint and turn the cooling off at approximately 0.5" below the setpoint. | 0.5 |
| Heating Swing | dFHE 04 | The heating swing setting is adjustable from 0.2" to 2". For example: A swing setting of 0.5" will turn the heating on at approximately 0.5" below the setpoint and turn the heating off at approximately 0.5" above the setpoint. | 0.4 |

Set Time

1. Press **TIME**
2. Day of the week will be flashing. Use the **+** or **-** key to select the current day of the week.
3. Press **TIME**
4. The current hour is flashing. Use the **+** or **-** key to select the current hour. When using 12-hour time, make sure the correct a.m. or p.m. choice is selected.
5. Press **TIME**
6. Minutes are now flashing. Use the **+** or **-** key to select current minutes.
7. Press **HOLD/RUN** when completed.

Programming

All of our programmable thermostats are shipped with an energy saving pre-program. You can customize this default program by following the steps on page 16.

Your thermostat can be programmed to have all the weekdays the same, a separate program for Saturday, and a separate program for Sunday. There are four time periods for each program (**WAKE, LEAVE, RETURN, SLEEP**).

| Factory Default Program | | | | |
|-------------------------|--------|-------|-----------------------------|-----------------------------|
| Day of the Week | Events | Time | Setpoint Temperature (HEAT) | Setpoint Temperature (COOL) |
| Weekday | Wake | 6 AM | 70°F (21°C) | 75°F (24°C) |
| | Leave | 8 AM | 62°F (17°C) | 83°F (28°C) |
| | Return | 6 PM | 70°F (21°C) | 75°F (24°C) |
| | Sleep | 10 PM | 62°F (17°C) | 78°F (26°C) |
| Saturday | Wake | 6 AM | 70°F (21°C) | 75°F (24°C) |
| | Leave | 8 AM | 62°F (17°C) | 83°F (28°C) |
| | Return | 6 PM | 70°F (21°C) | 75°F (24°C) |
| | Sleep | 10 PM | 62°F (17°C) | 78°F (26°C) |
| Sunday | Wake | 6 AM | 70°F (21°C) | 75°F (24°C) |
| | Leave | 8 AM | 62°F (17°C) | 83°F (28°C) |
| | Return | 6 PM | 70°F (21°C) | 75°F (24°C) |
| | Sleep | 10 PM | 62°F (17°C) | 78°F (26°C) |

You can use the table below to plan your customized program schedule.

| Custom Program | | | | |
|-----------------|--------|------|-----------------------------|-----------------------------|
| Day of the Week | Events | Time | Setpoint Temperature (HEAT) | Setpoint Temperature (COOL) |
| Weekday | Wake | | | |
| | Leave | | | |
| | Return | | | |
| | Sleep | | | |
| Saturday | Wake | | | |
| | Leave | | | |
| | Return | | | |
| | Sleep | | | |
| Sunday | Wake | | | |
| | Leave | | | |
| | Return | | | |
| | Sleep | | | |

Set Program Schedule

To customize your program schedule, follow these steps

Weekday:

1. Select **HEAT** or **COOL** with the system switch. **Note:** You have to program heat and cool each separately.
2. Press the **PROGRAM**
3. Monday-Friday is displayed and **WAKE** is shown. You are now programming the wake time period for the weekday setting.
4. Time is flashing. Use the **+** or **-** key to make your time selection for the weekday **WAKE** time period.
5. Press **PROGRAM**
6. The setpoint temperature is flashing. Use the **+** or **-** key to make your setpoint selection for the weekday wake period.
7. Press **PROGRAM**
8. Repeat steps 4 thru 7 for weekday **LEAVE** time period, for weekday **RETURN** time period, and for weekday **SLEEP** time period.

Saturday:

Repeat steps 4 thru 7 for the Saturday **WAKE** time period, **LEAVE** time period, **RETURN** time period, and for the Saturday **SLEEP** time period.

Sunday:

Repeat steps 4 thru 7 for the Sunday **WAKE** time period, **LEAVE** time period, **RETURN** time period, and for the Sunday **SLEEP** time period.